

DIWA-Pronto

Acid rinse aid

- ▲ Acid rinse aid for commercial dishwashers
- ▲ Fast, streak-free and mark-free drying
- ▲ Very low foaming even when used in higher concentrations
- ▲ For spotless dishes with shine



Area of application

For all types of alkali-resistant items made of porcelain, glass, stainless steel and plastic.

Application

Please test on a small inconspicuous spot before first application.

Mechanical dish washing:

The dosage values lie between 0.25–0.7 g/L of water.

Dosage takes place using the machine's integrated dosage mechanism or with the programmable KIEHL dosage devices. In order to achieve the best possible drying result, the dosage is set by a KIEHL service technician based on specific conditions (water hardness, level of soiling, type of machine). Consumption: no indication possible. Consumption depends on the specific conditions and specifications.

Ensure an optimum cleaning result by combining with the dishwasher detergents DIWA-Evo or DIWA-Basic.



Note

Kiehl accepts no liability or responsibility for damage caused as a result of incorrect use or application of the product. Not a consumer product according to 1999/44/EC Art. 1! For professional use only!

Ingredients (according to 648/2004/EC)

Nonionic surfactants 5–15%, organic acids, solubilizers, food-dye (CI 42051).

pH value (concentrate): approx. 2.5

pH value (ready-to-use solution): approx. 7

Art. No.	Packaging unit (PU)	Contents in kg	Numbers of PU per pallet
j567605	Carton of 2 x 5 L canisters	10.2	56
j567610	10 L canister	10.2	60
j567621	20 L canister	20.4	36
j567672	200 L drum	204	2